

Soft  
BY Playful™



Tootsie

RECHARGEABLE PALM MASSAGER

**USER MANUAL**

# Tootsie

## RECHARGEABLE PALM MASSAGER

The *Soft* by Playful™ Tootsie will be the softest, squishiest massager you'll ever touch. It's ribbed design and contoured lines will take over your intimate expectations, while the miniature size is ideal for on-the-go adventures.

Our #1 choice for newcomers, its powerful motor with eight vibration patterns will tantalise and tease with a touch of a button. Caress, rub and captivate attention with our super soft silicone as un-matched satisfaction awaits!

### KEY FEATURES:

- Single motor with ribbed feature
- 8 unique patterns of vibration (3 intensity levels)
- Super soft silicone
- 100% waterproof
- Whisper quiet
- Approx 120 minutes of playtime
- User-friendly control
- USB rechargeable
- Includes USB cable & user manual
- Two year Playful replacement warranty



8 VIBRATION  
PATTERNS



WHISPER  
QUIET



USB  
RECHARGEABLE




SUPER SOFT  
SILICONE



100%  
WATERPROOF

## TECHNICAL SPECIFICATIONS:



- Category: Rechargeable Palm Massager
- Motor: Single
- Battery: Rechargeable Li-on
- Noise: <50 dB
- Battery life: Approx 120 minutes
- Charge time: Approx 120 minutes
- Materials: Super soft silicone
- Size: 34mm(L) x 50mm(W) x 79mm(H)
- Product Code: MV-C1394-purple & MV-C1394-blue



## HOW TO USE:

### A ON/OFF/CHANGE VIBRATION MODE

### B CHARGING CONNECTION

1. Press and hold  for 1.5 seconds to turn on and hold for 3 seconds to turn off.
2. Click  to change through 8 different vibration patterns.

## VIBRATION PATTERNS:

1



2



3



4



5



6



7



8



## **CLEANING & STORAGE:**

- 1.** Always clean the massager thoroughly before and after each use.
- 2.** Warm water and antibacterial soap are recommended for cleaning the massager.
- 3.** Allow to dry after cleaning.
- 4.** Avoid exposure to direct sunlight.
- 5.** Store the massager in a dry/dust-free location or place in original packaging.

## **SAFETY:**

- 1.** Do not share the massager with others.
- 2.** Immediately stop using the massager if you feel uncomfortable.
- 3.** Only use the massager with a water-based lubricant.
- 4.** Stop use if the exterior of the massager is damaged or rough.
- 5.** Keep away from children.



## ATTENTION:

1. Charge prior to use.
2. Clean the massager with warm water and antibacterial soap or medical alcohol prior to use.
3. Only use the massager with premium water based lubricants. Do not use massage oil, hand cream or cleaning solutions, as these liquids will damage the massager and void the warranty.

**For maximum pleasure, apply water-based lubricant before use.**

## WARRANTY:

This product has a two year warranty with replacement for all faults and defects. Warranty is void if fault or defect is caused by misuse or improper handling. Warranty is null and void if product has been damaged or tampered with.

## DISCLAIMER:

Any of Playful's distributors, wholesalers and retailers shall not be negligent in any injury, death or unlawful act caused by use or misuse of Playful products. The product is a personal massager, any other use is not recommended and guaranteed. Playful will not be responsible for any complaints or claims if users of Playful products do not read and comply with instructions for use and safety.

email: [support@loveplayful.com](mailto:support@loveplayful.com)

web: [www.loveplayful.com](http://www.loveplayful.com)

## FOR NOVELTY USE ONLY.

Playful™

All rights reserved. **Made in China.**

